

Strut Nut Tool Set - 3pc

Description

3pc set for Macpherson struts designed for Volkswagen/Audi front and rear struts. Special top nut sockets which are designed to hold the damper shaft during removal and re-fitting. For Volkswagen Polo | Golf | Passat and Audi 80. Includes: No. 1 10.5mm, No. 2 12.5 mm, No. 3 14.5 mm.



Additional Information

- 3 piece set for Macpherson struts designed for Volkswagen/Audi front and rear struts.
- Special top nut sockets which are designed to hold the damper shaft during removal and re-fitting.
- Sizes 10.5mm, 12.5mm and 14.5mm.
- Used on Macpherson struts.
- Suitable for Volkswagen Polo | Golf | Passat and Audi 80.