

Gunson®

Ultrasonic Cleaner - Euro Plug ULTRASONIC CLEANSER - EURO PLUG

Part No. 77132



Instructions

Ultrasonic cleaner with Stainless Steel tank suitable for cleaning a wide range of items including small car parts | watches | coins | jewellery | CDs | DVDs | glasses | etc.

The ultrasonic wave in the solution causes alternating high and low pressures. During the low pressure stage, millions of microscopic bubbles form and grow.

During the high pressure stage the bubbles implode, releasing enormous amounts of energy. They work in all directions attacking surface and invading all recesses and openings.



www.gunson.co.uk



Distributed by The Tool Connection Ltd
Kineton Road, Southam, Warwickshire CV47 0DR
T +44 (0) 1926 815000 F +44 (0) 1926 815888
info@toolconnection.co.uk www.toolconnection.co.uk

Guarantee

If this product fails through faulty materials or workmanship, contact our service department direct on: +44 (0) 1926 818186. Normal wear & tear are excluded as are consumable items & abuse.

77132

Ultrasonic Cleaner - Euro Plug

Specification

Power supply	AC220-240v 50Hz (Euro plug)
Power	50 +/- 10w
Dimensions	228 x 183 x 158mm
Tank size	1300ml
Frequency	40 KHz
Weight	2.15kg

Please read all instructions before use.

Precautions

- Unplug from mains supply when not in use
- Keep cleaner on dry level surface and away from direct heat
- Do not leave unattended when in use
- Do not immerse the cleaner in water
- Only immerse waterproof items into the tank for cleaning
- Do not use with tortoiseshell
- Do not fill the tank with corrosive chemicals
- Do not attempt to dismantle
- Do not keep full of water when not in use
- Dry out with soft cloth after use
- Do not switch on with no water in the tank

Suitable for use on:

Jewellery	Necklaces, rings, earrings, bracelets, watch chains, waterproof watches
Glasses	Spectacles, sunglasses
Toiletries	Electric shaver heads, razor blades, dentures, combs, toothbrushes
Stationery	Pen tips, printer heads, inkjet cartridges, seals etc
Metal objects	Watch parts, ancient coins, badges, machine nozzles, spark plugs
Motor parts	Small items from engines etc including spark plugs, diesel injectors, carburettor parts etc.
Cutlery	Forks, knives, spoons etc.

Instructions For Use

1. Open lid and fill the Stainless Steel tank with water
2. Observe maximum and minimum levels
3. Immerse article into tank
4. Plug in the cleaner to the mains supply and switch **ON**.
5. Press the **SET** button to select the time (180sec is most popular)
6. By pressing the **SET** button the 5 options will appear
7. Press **ON** to start cleaning (blue light will appear)
8. An audible sound will show the cleaner is working
9. The cleaner will stop when 000 is reached and the blue light will go out
10. If you need to stop during the programme, press the **OFF** button and **ON** again to continue
11. If repeat cleaning is required repeat the steps above
12. When job is complete unplug cleaner, lift the lid and remove article
13. Pour out the water and dry tank ready for next use